


# Horizontal Rainwater Outlet

Step by step guide on installing a horizontal rainwater outlet to your next rubber roofing project.


1



## Step 1

Place the outlet through the wall and mark around it using a crayon or similar, allowing an additional 1cm around the perimeter.


2



## Step 2

Stir thoroughly and prime the underside of the outlet and the marked area on the rubber using a quick scrubber pad and handle. Allow both surfaces to dry.


3



## Step 3

Mate the outlet to the rubber and seal in place using a penny and silicone roller.


4



## Step 4

Round the corners of the 18" Flashing tape (Horizontal flashing kit) with scissors and neatly position over outlet. Mark the perimeter with crayon.


5



### Step 5

Prime the rubber and outlet using the quick scrubber pad and handle and extend primer beyond the crayon line by 2cm and into the mouth of the outlet by 100mm.

6



### Step 6

Once touch dry, working from the bottom, position the 18" Flashing tape and carefully remove the backing paper. Ensure it is tightly sealed into the corners and use a penny and silicone roller. Carefully cut the sides and top at the aperture and allow flap to drop into the primed outlet.